



DR-SM-X-XX

1 INSTALL DRAWER

Place the left and right drawer covers (B & C) over the sides of the drawer assembly as shown and set on the desktop to align.

Attach the Drawer to the underside of the worksurface using the 5 x 20mm Screws (D) 4x.

Note: Mount the front of the drawer 1" from the front edge of the worksurface.

One side of drawer should be flush with the inside face of the Frame Side Bar.

