






PARTS LIST

A

Adjustable Clasp 4x
105479

B





Adjustable Clasp Base 4x
105478

C


Laptop Clip Shoe 4x
106096




1




OR




OR




2




3





OR

**LAPTOP CLIP SHOES**

For ultra thin laptops/tablet PCs:
Install the laptop clip shoes (item C) that
are provided to ensure a secure grasp.

