

























# PARTS LIST

<p>A Mount Column 1x 401328</p> 	<p>F 3/8-16 x 1" Flat Socket Cap Screw 1x 701124</p> 	<p>K 1/2-13 x 3" Socket Set Screw 1x 701126</p> 	<p>P Dog Washer 1x 105189</p> 	<p>U 3/32" Allen Wrench 1x 700146</p> 
<p>B Base Plate 1x 406656</p> 	<p>G 3/8-16 x 1/2" BHSCS 1x 702898</p> 	<p>L Monitor Tilter 1x 405397</p> 	<p>Q 10-32 x 3/8" FPhMS w/Lock Patch 1x 705198</p> 	<p>V 7/32" Allen Wrench 1x 701127</p> 
<p>C Large "L" Bracket 1x 701117</p> 	<p>H 3/8-16 Nylon Stop Nut 1x 701418</p> 	<p>M 75/100mm VESA Adapter Plate 1x 105587</p> 	<p>R Forearm Cable Cap 1x 115584</p> 	
<p>D Small "L" Bracket 1x 111728</p> 	<p>I 3/8-16 x 7/8" Button Socket Cap Screw 1x 701122</p> 	<p>N 10-32 x 3/8" Phillips Flat Head Screw (4-pack) 1x 702281</p> 	<p>S Cable Cap 1x 114810</p> 	
<p>E Rectangular Spacer 1x 701544</p> 	<p>J 3/8-16 x 2-1/2" Hex Head Bolt 1x 700268</p> 	<p>O M4 x 12mm Phillips Pan Head Screw (4-pack) 1x 702096</p> 	<p>T 1/8" Allen Wrench 1x 701312</p> 	


## DESK CLAMP




1a




1b




1c






2a

8111-CUP




2b

8111-THRU




## WALL MOUNT




8111-WALL


3a




3b




## REVERSE WALL MOUNT




4a




4b




# GROMMET




5a




5b




5c




## SIDE BOLT




6a





6b


















**IMPORTANT!**


- Monitor must be on arm
- Arm must be in mount



Press the arm down to approximately parallel with the desk prior to turning the strength adjustment screw.




If the arm **drifts upward**, turn the adjustment screw clockwise.



If the arm **drifts downward**, turn the adjustment screw counter-clockwise.

Depending on the weight of your monitor, **you may have to make 15-20 turns.**

**OPTIONAL ADJUSTMENT**

**In some instances**, an additional counterbalance adjustment may be needed to allow the arm's instant height adjustment function to work properly.

If your arm is not staying in position after performing step 11, tighten the adjustment screw as shown.

