


PTS-04-LANE-WK


Installation Instructions




Human Active Technology


800 524 2744 customerservice@team-hat.com team-hat.com

PARTS LIST













ROTATION


Placement of the two rotation stop screws in the outer ring determine the amount of payment terminal rotation. You can remove the screws from their original location and place them in any of the holes in the outer ring to allow for the amount of desired rotation.







NO ROTATION

There are rotation stop ribs underneath the top portion of the mount that can be placed directly over the rotation stop screw or pin. This positioning will prevent the payment terminal from rotating. Determine the proper rotation stop screw location for your installation.







OR



