

















# PARTS LIST

|                                                                                                                                                                              |                                                                                                                                       |                                                                                                                                          |                                                                                                                                         |                                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>A Elle Gable 30" 2x<br/>R018 130</p>                                            | <p>F Switch Bracket 45° 1x<br/>RM-405-3</p>          | <p>K ø 4 x 16mm PH Wood Screw 2x<br/>R011 500</p>     | <p>P Cable Tray Sidepart 2x<br/>R033 210</p>         | <p>U Control Box CBD6S 1x<br/>RM-403-5-P1</p>                |
| <p>B Crossbar 2x<br/>Top Mount R063 198<br/>Enshrined Mount R063 199</p>                    | <p>G Switch DPF1K 1x<br/>RM-404-5</p>                | <p>L ø 5 x 50mm FH Wood Screw 2x<br/>R011 526</p>     | <p>Q Cable Tray Center 1x<br/>R033 211</p>           | <p>V Motor Cable (2m) 4x<br/>RN-401-2</p>                    |
| <p>C Crossbar Shroud 1x<br/>R088 300</p>                                                    | <p>H M8 x 20 Flange Head Screw 6x<br/>R011020</p>    | <p>M ø 5 x 20mm FH Wood Screw 33x<br/>R011 530</p>    | <p>R Slide Bushing 4x<br/>R015 148</p>               | <p>W Power Cable (3.2m) 1x<br/>CAB0015942</p>                |
| <p>D Sliding Top Sidebar 2x<br/>Top Mount R033 194/5*<br/>Enshrined Mount R033 196/7*</p>  | <p>I ø 4 x 45mm PH Wood Screw 2x<br/>R011 520</p>  | <p>N M8 x 20 Countersunk Screw 8x<br/>R011 022</p>  | <p>S Slide Washer ø 17 x 2 4x<br/>R015 192</p>     | <p>X Gyroscopic Collision Sensor 1x<br/>DS100001DK-00</p>  |
| <p>E Hat Profile 1x<br/>R033 209</p>                                                       | <p>J Cable Clip Sticker 1x<br/>R010 206</p>        | <p>O M6 x 10 Flange Head Screw 2x<br/>R011 073</p>  | <p>T ø 5 x 25mm FH Wood Screw 4x<br/>R011 528</p>  | <p>Y Velcro Strip 4x<br/>R010 250</p>                      |

PARTS LIST (CONTINUED)

Z                      Glider    4x  
                         R011 917




AA                    Mounting Pad for Glider    4x  
                         R010 204




BB                    Push Rivet    4x  
                         R010 232




BB                    4mm Wrench    1x  
                         R011 921




CC                    5mm Wrench    1x  
                         R011 904






1






**Caution:** Mount the crossbar in the holes next to where the cables come out of the gable.




Ø  
(2x)





Adjust the crossbar to the desired length  
and use the holes in part C to lock it in place.  
Each hole represents a 1" increment,  
adjusts from 48"-72".





















M  
(9x)




K  
(2x)






**Caution:** Leave the power turned off until all cables are connected.



**Top Mount**



**Enshrined Mount**