


7000 SERIES

Installation Instructions



Human Active Technology

800 524 2744 customerservice@team-hat.com team-hat.com

Note: Your configuration may differ than shown above.

	A Single Top Down Mount 8524	B Dual Top Down Mount 8524-2	C 180 Degree Rotation Stop 108208-180	D M6 x 1 x 18mm PhPHS 105304	E Quick Connect VESA Plate 114808	F Monitor Tilter 8500 Tilter
				Daning)		
7000						
	1x	-	_	-	1x	1x
7000-2						
	-	1x	2x	2x	2x	-
8524-TM-CK						
	-	-	_	-	_	_

PARTS LIST CONTINUED

	G Slider 416088	H M4 x 12mm PhPHS 701153	l Dog Washer 105189	J 10-32 x 3/8" FPhMS 705198	K Forearm Cable Cap 115584	L Cable Cap 114810
7000						
	_	4x	1x	1x	1x	1x
7000-2						
	2x	8x	2x	2x	2x	2x
8524-TM-CK						
	-	_	_	-	_	_


PARTS LIST CONTINUED


	M 3/32" Allen Wrench 700146	N 1/8" Allen Wrench 701312	O 7/32" Allen Wrench 701127	P 4mm Allen Wrench 709877	Q 5mm Allen Wrench 710838	R 6mm Allen Wrench 717654
7000						
	1x	1x	1x	_	_	1x
7000-2						
	1x	1x	1x	1x	1x	_
8524-TM-CK						
	-	-	-	-	-	-


PARTS LIST CONTINUED


	S M8 x 100mm SHCS 712262	T Spacer 701544	U M8 x 1.25 Lock Nut 710015
	@Miniminimin		
7000			
	_	-	_
7000-2			
	-	-	-
8524-TM-CK			
	1x	1x	1x

DESK CLAMP CONFIGURATION - TOP DOWN MOUNT












2







THRU-DESK CONFIGURATION* - TOP DOWN MOUNT









DESK CLAMP CONFIGURATION - TOP DOWN MOUNT DUAL



THRU-DESK CONFIGURATION* - TOP DOWN MOUNT DUAL









INSERT ARM(S) IN MOUNT




7000 SINGLE MONITOR ARM






TILTER W/ QUICK CONNECT VESA PLATE ASSEMBLY



SLIDER W/ QUICK CONNECT VESA PLATE ASSEMBLY




COUNTERBALANCE ADJUSTMENT





IMPORTANT!

- · Monitor must be on arm
- · Arm must be in mount











If the arm **drifts upward,** turn the adjustment screw clockwise.




If the arm **drifts downward**, turn the adjustment screw counter-clockwise.

Depending on the weight of your monitor, you may have to make 15-20 turns.

ROTATION FRICTION ADJUSTMENT





CABLE MANAGEMENT



