



















VERTICAL WALL TRACK


Installation Instructions




HM-WT004-800


PARTS LIST


<div>A</div> <div>Wall Track Mount 2x 8328</div> <div></div>	<div>F</div> <div>10-32 x 3/8" FPhMS w/Lock Patch 2x 705198</div> <div></div>	<div>K</div> <div>Cable Cap 2x 114810</div> <div></div>	<div>P</div> <div>3/32" Allen Wrench 1x 700146</div> <div></div>
<div>B</div> <div>M4 x 12mm Phillips Pan Head Screw (4-pack) 1x 702096</div> <div></div>	<div>G</div> <div>10-32 x 3/8" PhPHS (4-pack) 1x 702281</div> <div></div>	<div>L</div> <div>Track Mount Cable Cap 2x 104599</div> <div></div>	<div>Q</div> <div>7/32" Allen Wrench 1x 701127</div> <div></div>
<div>C</div> <div>Quick Connect VESA Plate 1x 114808</div> <div></div>	<div>H</div> <div>Monitor Tilter 1x 405397</div> <div></div>	<div>M</div> <div>Wall Track End Cap 2x 104596</div> <div></div>	
<div>D</div> <div>Monitor Tilter 1x 8500 Tilter</div> <div></div>	<div>I</div> <div>Mouse Pad 1x 700865</div> <div></div>	<div>N</div> <div>Wall Track Cable Cap 1x 104985-31</div> <div></div>	
<div>E</div> <div>Dog Washer 2x 105189</div> <div></div>	<div>J</div> <div>Forearm Cable Cap 1x 115584</div> <div></div>	<div>O</div> <div>1/8" Allen Wrench 1x 701312</div> <div></div>	





Mounting hardware not included.
Use appropriate hardware to
secure to the mounting surface.






2x
























IMPORTANT!

- Monitor and keyboard tray with peripherals must be on arms
- Arm must be in mount




Press the arm down to a horizontal position
prior to turning the strength
adjustment screw.

2x



If the arm **drifts upward**,
turn the adjustment screw
clockwise.



If the arm **drifts downward**,
turn the adjustment screw
counter-clockwise.

Depending on the weight of your monitor, **you may have to make 15-20 turns.**

